

Installation Instructions  
FD-FVK-1



Ford Full Size Van Models  
E-Series 1992-2014

Kit Contains:

- |   |                 |                  |
|---|-----------------|------------------|
| 1 | Back Door Left  | FD-1A-Rear-Left  |
| 1 | Back Door Right | FD-1B-Rear-Right |
| 1 | Side Door Left  | FD-1C-Side-Left  |
| 1 | Side Door Right | FD-1D-Side-Right |

Tools Required for Installation:

- T27 Star Bit Socket
- T40 Star Bit Socket
- Long Nose Pliers

**SLICK LOCKS SPINNERS REQUIRED ON ALL KITS**

**WATCH INSTALLATION VIDEO ON [SLICKLOCKS.COM](http://SLICKLOCKS.COM)**

**Thank you for purchasing our product! Feel free to call with any questions (888) 430-1994**

US PATENT 8,496,276B2

### **STEP 1**

Begin by applying a spray lubricant to back side threads of bolts holding left rear lock striker plate in place. Using the T40 star socket remove striker plate. Hold FD1A-Rear Left bracket over two striker plate holes. Reinstall left side striker plate and bolts on top of FD1A-Rear Left bracket. Hold bracket firm against body of door and retighten star bit bolts.

### **STEP 2**

Using T27 star bit socket remove two latch bolts from right rear door leave 3<sup>rd</sup> screw in place to hold latch in place. Pull weather stripping out from door and pull plastic retaining clip loose with long nose pliers. Install right rear bracket under weather stripping and reinsert retaining clip through small bracket hole. Reinstall two 6mm star head bolts using T27 socket. Only hand-tighten this side.

**CAUTION** - Slowly close left then right door making sure weather stripping clears left bracket - If vehicle is older model you may need to trim off 1/8 inch of bottom side of rubber that contacts new right side bracket. Once doors are closed, align lock holes with RD Pin - (dowel pin, drill bit, etc.) When you are satisfied with alignment, slowly open right side door and torque down both bolts. Shut rear door firmly. If lock fits nicely move on to side doors for installation of brackets using same process. If lock is difficult to slide on and off or difficult to close - Realign right side until desired fit is achieved - brackets can also be modified with round file or drilling center hole to accommodate various lock brands. Be careful to not damage your vehicles painted finish.