

Installation Instructions
FD-FVK-SLIDE



Ford Sliding Van Models
E-Series 1992-2014

Kit Contains:

- | | | |
|---|-----------------|------------------|
| 1 | Back Door Left | FD-1A-Rear-Left |
| 1 | Back Door Right | FD-1B-Rear-Right |
| 1 | Slide Door | FD-1-Slide |

Tools Required for Installation:

- T27 Star Bit Socket
- T40 Star Bit Socket
- Long Nose Pliers

SLICK LOCKS SPINNERS REQUIRED ON ALL KITS

SLIDE DOOR

STEP 1

Slide door to FULL open position- locate lock striker plate at rear of van door jam. Slider bracket mounts at rear edge of sliding door. Remove two T-40 star bolts- holding on striker plate, place slider bracket over mounting bolts- use grease pencil to mark where bracket lays on outside of van side panel. Apply clear tape protector directly on van surface under round end of bracket to protect paint.

STEP 2

Hold bracket in place and reinstall striker plate on bracket- tighten star bolts- slowly close door and check for proper clearances. Close door firmly and apply clear tape protector on sliding door edge to protect paint from lock.

REAR INSTRUCTIONS ON BACK

REAR DOORS

STEP 1

Begin by applying a spray lubricant to back side threads of bolts holding left rear lock striker plate in place. Using the T40 star socket remove striker plate. Hold FD1A-Rear Left bracket over two striker plate holes. Reinstall left side striker plate and bolts on top of FD1A-Rear Left bracket. Hold bracket firm against body of door and retighten star bit bolts.

STEP 2

Using T27 star bit socket remove two latch bolts from right rear door leave 3rd screw in place to hold latch in place. Pull weather stripping out from door and pull plastic retaining clip loose with long nose pliers. Install right rear bracket under weather stripping and reinsert retaining clip through small bracket hole. Reinstall two 6mm star head bolts using T27 socket. Only hand-tighten this side.

CAUTION - Slowly close left then right door making sure weather stripping clears left bracket - If vehicle is older model you may need to trim off 1/8 inch of bottom side of rubber that contacts new right side bracket. Once doors are closed, align lock holes with RD Pin - (dowel pin, drill bit, etc.) When you are satisfied with alignment, slowly open right side door and torque down both bolts. Shut rear door firmly. If lock fits nicely move on to side doors for installation of brackets using same process.

If lock is difficult to slide on and off or difficult to close - Realign right side until desired fit is achieved - brackets can also be modified with round file or drilling center hole to accommodate various lock brands. Be careful to not damage your vehicles painted finish.

WATCH INSTALLATION VIDEO ON SLICKLOCKS.COM

Thank you for purchasing our product! Feel free to call with any questions (888) 430-1994

US PATENT 8,496,276B2